


FAN KIT

Models: UZY5/PUZY5

NOTE: These fan kits can easily be installed when the fireplace has a pre-installed junction box. You just have to plug them in.

Rating: 120 volt, 60HZ , .63A



The fans have magnetic blower mounts. The junction box (factory installed on approved fireplaces for the use of this fan kit) must be connected to 110VAC service before permanently enclosing the fireplace. The access hole for connecting the 110VAC is located on the lower back right exterior side of the fireplace.

INSTALLATION INSTRUCTIONS:

1. Open the bottom louver of the fireplace.
2. Place the fan kit into the fireplace opening 1" from the back of the fireplace.
3. Install the thermo-disk fan activator under the firebox toward the right side.
Note; the fan activator has a magnetic mount.

NOTE: The fireplace must be electrically connected and grounded in accordance with local codes or, in the absence of local codes, with the current CSA C22.1 Canadian Electrical Code. For U.S.A. installations, follow local codes and the National Electrical Code ANSI/NFPA No. 70.

CAUTION: Should this fan kit require servicing, the power supply must be disconnected.

These fans do not need regular maintenance however, periodic cleaning is required. Check the area under the firebox and in front of the fans and wipe or vacuum at least once a month during the operating season.